

01 - Assembly Of Kings Range



To assemble a cutlery utensil and a handle, you simply push the utensil spigot into the hole in the handle. If the handle needs to be built up further, sleeves can be added. These must be fitted over the slim handle (AA5543) first, and then the handle attached to the utensil spigot in the manner described above. If a double ended utensil is required, handles with a hole in both ends are available. The utensils can be rotated to the position required. When using the strap, it is placed between the handle and cutlery spigot or end piece.